



### Adjustable Air Strippers with plain and screw thread fitting.

Thank you for your purchase. Please read these instructions before fitting.

Your package should contain –  
1 off Airstripper body with cone.  
1 off 2.0mm allen key

#### **Safety first.**

Observe safe practices when handling your rifle and follow the manufacturer's safety instructions when doing so.

Take extra care when working on your rifle.


Ensure that the rifle is switched OFF and the safety catch is set to safe and is absolutely not loaded with pellets and the area is safe.

Important - Fitting the stripper should not require any force and be a smooth sliding fit on the barrel or easy to turn on to the thread.

1. Before fitting, please check the outside and end of the barrel is free from any marks, scuffs or burrs of any kind.

If the end of the barrel is not completely smooth the stripper may get stuck and may require force to remove it again damaging the stripper, barrel or both.  
If any marks are present they should be very carefully removed with fine emery or a fine abrasive stone.

2. Apply a thin covering of light oil on the end of the barrel where the stripper will fit.  
3. Gently slide the stripper in to position – no force should be needed. Don't force!  
4. Gently 'nlp' the locating grub screws.  
5. The position of the stripper cone should be approximately 5mm from the end of the barrel. This is a good starting point and test shooting should be carried out to determine the optimum cone–barrel gap where the pellets form the tightest groups.



Cone

End of barrel

5mm gap